


T.M. SMITH TOOL

INTERNATIONAL CORPORATION

360 HUBBARD AVE ◆ P.O. BOX 1065 MT. CLEMENS, MICHIGAN 48046-1065 (586) 468-1465 · (800) 521-4894 FAX: (586) 468-7190 · www.tmsmith.com


BALL-LOCK[™] QUICK CHANGE DRILLING SYSTEM

USAGE AND DIRECTIONS



OSA Ball-Lock[™] Stub Series

Spindle Mounting Screw is .500 back from spindle face



Without the tool holder inserted, install the mounting screw with an Allen wrench so that it is below the O.D. of spindle, as shown...




Align the hole on the stub body with the hole on the outer shell. Slide the OSA assembly over the spindle so that holes are aligned with the tapped hole in the spindle.





Locking OSA assembly to Spindle








OSA Ball-Lock[™] Standard Series


Spindle Mounting Screw is Greater than .500 back from spindle face





OSA Ball-Lock[™] Standard Series

Spindle Mounting Screw is Greater than .500 back from spindle face



Slide the OSA over the spindle, aligning one of the 3 mounting holes with the tapped hole in the spindle.






Mounting Hole Options

Note the (3) possible mounting holes in the OSA assembly.

The OSA should be mounted on the spindled using the hole that allow the outer and inner shell of OSA to be flush when tool holder is inserted and locked in place.









Mounting OSA to Spindle








Inserting Tool Holder for both, Stub and Standard, Ball-Lock™OSA's

With the outer shell pulled forward, insert the tool holder into the spindle, once fully inserted, release the OSA outer shell, allowing it to fall into the locked position, securing the tool holder in place.









Ball-Lock[™] Conversion Nut

OSA Ball-Lock[™]Conversion Nuts can be used on standard ACME shank tooling.





the Ball-Lock conversion nut and follow Instructions on previous pages.



For additional information, please contact our sales team at:

Phone: 800-521-4894

586-468-1465

Fax: 586468-7190

E-mail: sales@tmsmith.com



